




Just weld and cut

Plasma Cutter Operation Manual



RBC6000/RBC6000D/RBC6000 PRO/RBC6000D PRO/RBC6000D MAX
RBC6000L/RBC6000DL/RBC6000L PRO/RBC6000DL PRO

Reboot

Just weld and cut



VIP-WELDER SERVICE CENTER



E-Mail

Europe and UK:Service-eu@mirthtek.com

North America:Service@mirthtek.com

South America and others:nancy@weldvip-service.com



Mobile

+86 18938887689



Wechat

+86 18938887689



WhatsApp

+86 18938887689



Facebook

Reboot Welding Solutions



Ins

weldflowhub

Contents


1、Product Brief Introduction	01
2、Accessories list	02
2.1 Touch Arc RBC6000、RBC6000 PRO、RBC6000D、RBC6000D PRO、RBC6000D MAX	02
2.2 Pilot Arc RBC6000L、RBC6000DL、RBC6000L PRO、RBC6000DL PRO	03
3、Installation of Air Regulator	04
3.1 RBC6000、RBC6000D、RBC6000L、RBC6000DL	04
3.2 RBC6000 PRO、RBC6000L PRO、RBC6000D PRO、RBC6000DL PRO	05
4、Air compressor connection	06
5、How to Work	07
6、Operation panel interface	08
7、Start Cutting	09
7.1 Edge cutting	09
7.2 Piercing Cutting	09
8、Hand torch cutting Show	10
8.1 Torch tip height & position	10
8.2 Speed and Amperage	10
9、Cutting Performance Impact	11
10、Cutting Guide	12

1、Product Brief Introduction

 Model	RBC6000D RBC6000DL RBC6000D PRO RBC6000DL PRO RBC6000D MAX	 Input Voltage	AC120 50-60Hz AC240 50-60Hz	 Circuit Breaker	120V:55A 240V:40A	
	RBC6000 RBC6000L RBC6000 PRO RBC6000L PRO		AC240V 50-60HZ		240V:40A	
 Duty Cycle	40%	 Current Range	15-60A	 Voltage Range	86-104V	
 Efficiency	75%	 Protection Class	IP21S	 Power Factor	0.85	
 No-Load Voltage	325V	 Rated Power	7KVA	 Weight (Kg)	7KG	
 Insulation Class	H	 Size (mm)	390*220*300mm	 Air flow	180~200 l/min 6.4~7.1 CFM	
 1.0mm	 120V-35A			 240V-60A		
		 δClear	 δmax		 δClear	 δmax
	70psi	8mm	12mm	75psi	12mm	16mm
	70psi	8mm	12mm	75psi	12mm	16mm
	70psi	2mm	4mm	75psi	3mm	6mm
	70psi	2mm	3mm	75psi	3mm	5mm


2. Accessories list

2.1 Touch Arc RBC6000、RBC6000 PRO、RBC6000D、RBC6000D PRO、RBC6000D MAX




PT31 Gun

Replace Parts:2,4




2.2 Pilot Arc RBC6000L、RBC6000DL、RBC6000L PRO、RBC6000DL PRO






AG60 Gun

Replace Parts:3,4






3、Installation of Air Regulator

3.1 RBC6000、RBC6000D、RBC6000L、RBC6000DL




Air Pressure Display

3.2 RBC6000 PRO、RBC6000L PRO、RBC6000D PRO、RBC6000DL PRO




Air Pressure Display


4. Air compressor connection




5.1 Touch ARC





5.2 Pilot Arc





5.3 Pilot Arc Mesh



5.4 Attention






6、Operation panel interface




		
	<p>RBC6000/RBC6000D RBC6000L/RBC6000DL</p>	<p>RBC6000 PRO/RBC6000D PRO RBC6000L PRO/RBC6000DL PRO RBC6000D MAX</p>
<p>①</p>	<p>Current Adjust Knob</p>	
<p>②</p>	<p>Current Display</p>	
<p>③</p>		<p>Air Pressure Display</p>
<p>④</p>		<p>【Post Air】 【Pilot Arc】 【Air Pressure】 Choice</p>
<p>⑤</p>		<p>【2T】 【4T】 【Air Testing】 Choice</p>

7. Start Cutting

7.1 Edge cutting







7.2 Piercing Cutting







8、 Hand torch cutting Show


8.1 Torch tip height & position



8.2 Speed and Amperage



9、Cutting Performance Impact



 <h2 style="margin: 0;">WARNING</h2>	
<p>Do Not Remove, Destroy, Or Cover This Label.</p>	
 <p>ELECTRIC SHOCK can kill</p> <ul style="list-style-type: none"> • Wear dry protective apparel • Avoid contacting work piece or ground • Avoid contact with electrically live parts • Do not touch work piece and welding wire at the same time • Use only recommended cables and cords • Connect ground clamp as close to the welding area as possible • Disconnect power when servicing this welder 	 <p>FIRE HAZARD</p> <ul style="list-style-type: none"> • Remove all flammable materials within 35 feet of the cutting arc • Keep flying spards from entering cracks or hidden areas • Keep a fire extinguisher close • Wear oil-free garments without pockets or cuffs • Do not weld on closed containers
 <p>FUMES AND GASES can injure your health</p> <ul style="list-style-type: none"> • Do not breathe fumes emitted by the welding process • Do not weld coated or plated materials (galvanized, cadmium, zinc, mercury, barium) • Use ventilator when necessary • Know the danger of materials you are welding • Refer to MSDS sheets for welding wire and materials being welded 	 <p>ARC RAYS can injury eyes and burn</p> <ul style="list-style-type: none"> • Always wear a helmet with full face and neck protection with shade#10 lens • Use helmet that meets ANSL standards • Wear correct eye, ear, and body protection • Warn people in the cutting area when you are staring an arc
<p>Read the operator's manual for more safety information</p>	
 <p>PLASMA ARC CAN CAUSE INJURY</p> <ul style="list-style-type: none"> • Use torch(es) specified in instruction manual • Disconnect power source before disassembly of the torch • The shield cup must be installed prior to operation of the torch • Do not point plasma torch at body parts • Do not hold material near cutting path • Keep clear of torch tip while in use 	 <p>MAGNETIC FIELDS</p> <ul style="list-style-type: none"> • Keep people with pace makers away from your cutting area • Keep PLASMA torch and ground cables on the same side of your body • Do not wrap cable around your body while cutting


10、Cutting Guide

1. Rest assured, 95% of all issues with the operation of the machine can be resolved by following the steps below.

2. Three key points for using a cutting machine. Beginners are advised to start with cutting thin sheets and practice more.

Before cutting:


1. Ensure the torch head is perpendicular to the workpiece.
2. Position the midpoint of the holes in the nozzle in line with the edge of the workpiece.
3. Start the arc by pressing the torch trigger and move slowly forward, stopping the torch head until the cutting arc is as vertical as possible before proceeding.
4. If the cut isn't penetrating, slow down the torch movement and try cutting again elsewhere.
5. It's normal for beginners to struggle at first, so start with thinner plates, around 3mm.



10、Cutting Guide

During cutting:


- 1.Keep the torch head perpendicular to the workpiece throughout the cutting process.
- 2.Ensure the angle of the downward spark spray is no more than 30 degrees from vertical.
- 3.Slow down the torch movement if the angle is too large until it's less than 30 degrees.
- 4.If there's a spark spray back, stop cutting and restart from a new point.



10、Cutting Guide

Ending Cutting:

- 1.Pause the torch momentarily when reaching the end of the workpiece,waiting for the cutting arc to become as vertical as possible and the edge of the workpiece to turn red before slowly moving the torch forward to complete the cut.
- 2.If there's a spark spray back, pause cutting immediately to avoid damaging the torch parts.
- 3.It's normal for beginners to experience spark spray back,so prepare extra parts and practice more.



10、Cutting Guide

3. Pay attention to timely replacement of vulnerable parts.

① Fitting



If the Hafnium wire at the electrode tip is Deformed nozzles must be replaced recessed by 2mm, replace the electrode; Electrode both ends can be used.




Scan to buy consumables on shops




10、Cutting Guide


② cutting torch setup

PT31 Setup



AG60 Setup





Reboot

Just weld and cut

Advanced welding and cutting technology
leading the industry trend.

